



SPK-40-SP

40 FOOT RETRACTABLE SPEAKER CABLE

photos




description

INSTANTLY WIND UP OVER 40 FEET OF SPEAKER CABLE WITH 1 PULL! THE STAGE NINJA SPK-40-SP IS EQUIPPED WITH THE HIGHEST QUALITY SPEAKER CABLE WITH A ROBUST RUBBER JACKET. THE RETRACTABLE END IS 40 FEET WITH 16/2 AWG SPEAKER CABLE AND A GENUINE NEUTRIK NL2FX SPEAKON CONNECTOR. THE STATIC END IS 6 FEET WITH A GENUINE NEUTRIK NL2FX SPEAKON CONNECTOR. THE COMPACT BLACK STEEL HOUSING FEATURES A QUICK-RELEASE WALL OR CEILING MOUNTING BRACKET. CONSTANT TENSION AVAILABLE UPON REQUEST. ELIMINATES CORD WINDING, CORD TANGLES AND STAGE/STUDIO CLUTTER WITH INSTANT CABLE RETRACTION. ORGANIZE YOUR SOUND WITH THE SPK-40-SP.

AVAILABLE IN CONSTANT TENSION.

details



WEIGHT = 9 LBS
 DIMS = 10" X 3.5"
 MADE IN USA

WARNING!!

Read all instructions. Keep out of reach of children. The Stage Ninja® Retractable Cord is not a toy! This product can cause injury including, burns, cuts, eye injuries, or amputation if cord is used improperly. Recoil can cause injuries, especially when recoil is unexpected. When unplugging from instrument, hold cable end when retracting to maintain control of recoil. Do not wrap Cord around finger, neck, arm, leg, or other appendage or body part. The Retractable Cord is for use by responsible adults only. Do not allow anyone to touch or come in contact with the Retractable Cord while in use. Unplug Cord from musical instrument and amplifier when not using. Stop using the Retractable Cord if it becomes frayed, damaged, shows other signs of significant wear and tear, or does not function properly. Do not attempt to repair the Cord. Wear long pants to reduce the risk of leg burns and cuts from the Retractable Cord. Do not place hands, feet, head, or other appendage or body part near housing unit while Cord is extended. Please heed these warnings and use Retractable Cord with caution.