




STX-30-3

photos




30 FOOT RETRACTABLE POWER CABLE

description

INSTANT RETRACTION! THE STAGE NINJA STX-30-3-14 OFFERS CONSISTENT ORGANIZATION FOR YOUR WORK SPACE AND EFFICIENTLY REDUCES SET-UP AND TEAR DOWN-TIME. THE RETRACTABLE CORD IS 30 FEET OF SJTW 14/3 AWG CABLE WITH A 3-TAP HEAD AND A CIRCUIT BREAKER INSIDE THE OVERMOLDED END. THE STATIC MALE END IS 3 FEET THE COMPACT BLACK STEEL HOUSING FEATURES A REMOVABLE WALL OR CEILING MOUNTING BRACKET. CONSTANT TENSION AVAILABLE UPON REQUEST. STAGE NINJA POWER REELS HAVE THE STRONGEST RETRACTION ON THE MARKET.

1625 WATTS 125 VOLTS 13 AMPS. C/UL/US
CONSTANT TENSION AVAILABLE

details



WEIGHT = 9 LBS
DIMS = 11" X 3.5"
MADE IN USA

WARNING!!

Read all instructions. Keep out of reach of children. The Stage Ninja® Retractable Cord is not a toy! This product can cause injury including, burns, cuts, eye injuries, or amputation if cord is used improperly. Recoil can cause injuries, especially when recoil is unexpected. When unplugging from instrument, hold cable end when retracting to maintain control of recoil. Do not wrap Cord around finger, neck, arm, leg, or other appendage or body part. The Retractable Cord is for use by responsible adults only. Do not allow anyone to touch or come in contact with the Retractable Cord while in use. Unplug Cord from musical instrument and amplifier when not using. Stop using the Retractable Cord if it becomes frayed, damaged, shows other signs of significant wear and tear, or does not function properly. Do not attempt to repair the Cord. Wear long pants to reduce the risk of leg burns and cuts from the Retractable Cord. Do not place hands, feet, head, or other appendage or body part near housing unit while Cord is extended. Please heed these warnings and use Retractable Cord with caution.